CONTENTS

CHAP	TER 1	INTRODUCTIONS
1.1	Feature	25
1.2	Handli	ng Precautions
СНАР	TER 2	CONFIGURATIONS AND PRODUCT LIST
2.1	Systen	a Configurations
2.2	Produc	zts List
2.3	Power	ON Flow - chart
2.4	Progra	mming Flow - chart
СНАР	TER 3	SPECIFICATIONS
3.1	Genera	al Specifications
3.2	Perfor	mance Specifications
3.3	Parts a	nd Descrption
3.4	Key Fu	Inctions
3.5	Mode	Description
СНАР	TER 4	KEY OPERATIONS
4.1	Power	On
4.2	Mode	Change
4.3	Passwo	ord Registration
4.4	Passwo	ord Change and Disable
4.5	Progra	m Input and Modify
4.6	Step S	earch and Program Read
4.7	Progra	m Examples
4.8	Progra	m Insert
4.9	Progra	m Delete
4.10	0 Bit N	o. Search
4.1	1 Word	No. Search
4.12	2 Step	Monitor
4.13	3 Bit M	Ionitor
4.14	4 Word	Monitor
4.1	5 Bit/W	/ord forced On/Off

- 1 -

4.16	Current Value Change	37
4.17	Timer/Counter Input	38
4.18	Descriptions	40
4.19	Timer/Counter Monitor	41
4.20	Timer/Counter Preset Value Change	42
4.21	Timer/Counter Forced On/Off and Elapsed Value Change	43
4.22	HSC(High Speed Counter) Data Setting	45
4.23	HSC Data Setting with Default	47
4.24	Latch Area Setting	48
4.25	W.D.T Setting	49
4.26	Error Mode Setting	50
4.27	I/O Table Setting	51
4.28	I/O Table Monitor	52
4.29	Parameter Setting with Default	53
4.30	Trace Run	54
4.31	Step Break Run	56
4.32	Scan Run	57
4.33	Value Break Run	58
4.34	Program Partial Delete	60
4.35	Program Data Clear	61
4.36	Data Block Change	62
4.37	Block Move/Copy	63
4.38	Block Move/Copy Description	64
4.39	Program All Clear	65
4.40	EPROM Check	66
4.41	EPROM Write	67
4.42	EPROM Verify	68
4.43	EPROM Read	69
4.44	Scan Time Display	70
4.45	Scan Time/HSC Monitor (K10S/K30S/K60S)	71
4.46	RTC(Real Time Clock) Monitor and Setting (K10S/K30S/K60S/K200S//K300S//K1000S)	72
4.47	Hexadecimal Decimal Change	73

- 2 -

4.48	LCD Back Light On/Off	74
4.49	Buzzer Tone Control	75
4.50	PLC Station/Baud Rate Setting (K10S/K30S/K60S)	76
4.51	Baud Rate Setting	77
4.52	Link Parameter Setting	78
4.53	HS Link Parameter Setting	79
4.54	Link Control Setting	81
4.55	HS Link Enable Setting	83
4.56	Debug Output	84
4.57	Timer Setting	85
4.58	Interrupt Setting (1)	86
4.59	Interrupt Setting (2)	88
4.60	Force On/Off Setting	89
4.61	Force On/Off Enable Setting	90
4.62	Remote Connection Setting	91
4.63	Remote Disconnection Setting	92
4.64	PLC Information View	93
4.65	Program Insert/Delete During Run	94
4.66	PDI Slot Setting	95
4.67	C-Net Communication Setting	96
4.68	MASTER-K Function Comparison Table	97
СНАРТ	FD 5 TDOURI ESHOOTING	
51	MASTED K10/K60H/K200H (Indicated on the Word E05)	00
5.2	MASTER K500H/K1000H (Indicated on the Word F06)	100
5.2	MASTER K100/K100011 (Indicated on the Word F00)	100
5.5	CLOEA K2, K4, K5 (Indicated on the Word E06)	102
5.4	Z2005 Z2005 Z2005 Z10005 (Indicated on the Word F06)	103
3.5	x2005, x3005, x10005 (indicated on the word F00)	104
СНАРТ	ER 6 DIMENSIONS	107
СНАРТ	ER 7 KEW - 150S DIMENSIONS AND DESCRIPTIONS	108
[APPEN	DIX] HANDY LOADER COMMAND CODE TABLE	109

- 3 -

CHAPTER 1 INTRODUCTIONS

1.1 Features

Handy Loader, KLD-150S is a commonly used programming tool for MASTER-K series PLC. It has various features such as program editing/monitoring, special functions and mode setting (PGM, Pause, Run, Debug).

1) 4 Mode Operation	Program Mode
	Run Mode
	Debug Mode
	Pause Mode
2) Monitoring	
3) EPROM Writer Functions	Reading from EPROM
	Writing to EPROM
	Confirming of EPROM Clear
	Comparing EPROMs

4) LCD Back Light On/Off Function

1.2 Handling Precautions

1) Connection to MK series



2) Program back-up using KLD-400 graphic loader



- 5 -

CHAPTER 2 CONFIGURATION AND PRODUCT LIST

2.1 System Configuration



- 6 -

2.2 Product List

Unit	Туре	Descriptions
VID 1508	Handy	LCD-attached programming tool
RED- 1505	Loader	Loader cable(1.5m) is included
		EPROM(12.5V) Pack
KPM-128 KRM-256	Memory Pack	RAM Pack
KPM-256 KEW-150S		EPROM Writer
VI C 010	Loader Cable	MASTER - Loader cable for K10S/K10S1
KLC-010		(Not supplied with KLD-150S)
KLA-010	Adapter	9 : 9pin genda changer, Pin 2,3 Parallel
	nuapter	(Not supplied with KLD-150S)

- 7 -

2.3 Power On Flow - chart



- 8 -

2.4 Program Flow - Chart



- 9 -

CHAPTER 3 SPECIFICATIONS

Item	Specifications
Storage temperature range	- 10 50
Operating temperature range	0 40
Ambient humidity range	5 95% (Non-condensing)
ambience	Free from corrosive gases
Dimensions	$90W \times 175H \times 36D \text{ [mm]}$
Weight	420 g
Cooling method	Self cooling

3.1 General Specifications

3.2 Performance Specifications

Item	Specifications		
Available PLC	MASTER-K Series		
Power supply	Connected PLC. DC 5V 0.6A		
	Connected by loader cable		
with PLC	Interface : RS-232C, 9.6Kbps (K10S, K30S, K60S)		
what i be	38.4Kbps (K200S, K300S, K1000S)		
	16 character, 2 line Dot matrix LCD		
LCD display	LCD back light : On/Off by key operation		
	turned off automatically after 10 min. since last key operation		
	3 Mode LED. 3 Mode Key.		
	48 key - keypad		
Key pannel	Key-Buzzer function - Error or key operating		
	- On/Off select function		
Programming method	On-Line : Inputs program direct to PLC program area		
	Off-Line : KEW-150S and KLS-05A is required		
Complement 16K, 32K Byte EPROM			

- 10 -

3.3 Parts and Description



- 11 -

1) External power supply jack

A connector jack for external power supply

2) PLC connection port

Loader cable port. PLC can be connected to this port by loader cable.

3) LCD module

16 character, 2 line dot matrix LCD module is used.LCD back light makes it possible operating under dark environments.

4) PLC mode display LED

LEDs that indicates the current PLC mode. There is four mode according to the PLC status - RUN, PAUSE, PROGRAM, DEBUG mode

5) EPROM writer Connector

A connector for KEW - 150S(Option module). EPROM read, write, verify and blank check functions are available.

- 12 -

6) Key pad

Key type	Name	Function					
	RUN	Changes the PLC mode into RUN.					
Mode Key	DEB /PAU	Changes a PLC into PAUSE mode from RUN mode or into DEBUG mode from PROGRAM mode.					
	PGM	Changes the PLC mode into PROGRAM.					
Shift Key	SHFT	In order to execute a senconary function, press this key ahead of multi-function key. This key takes effect on only one execution.					
	ENT	Inputs user programs into the PLC program area or inputs user data into the data area. (D, T/C, M etc.)					
	CLR	Get back to the previous state. SHFT+CLR sweeps out the LCD. (Clear)					
	TEST	Can be used to change the word value such as current vlaue and set value of T/C or D register value.					
Execution	SRCH	search a command or bit in program or search the end of program(search)					
Key	DELT	Delete specific steps in user program.					
	INST	Insert specific steps in user program.					
	STEP ▼	Displays next step of user program or next bit, next card in monitoring status.					
	▲ STEP	Displays previous step of user program or previous bit, previous card in monitoring status.					
	LOAD	Used in LOAD, LOAD NOT, AND LOAD, OR LOAD					
Command	AND	Used in AND, AND NOT, AND LOAD					
Key	OR	Used in OR, OR NOT, OR LOAD					
	NOT	Used in LOAD NOT, AND NOT, OR NOT, NOT					

- 13 -

Key type	Name	Function
	OUT	OUT
	SET	SET
Command	RST	RST (Reset)
Key	FUN	Loads the application commands
	TMR	Loads timer-related functions (TON,TOFF,TMR,TMON,TRTG)
	CNT	Loads counter-related functions (CTU, CTD, CTUD, CTR)
	Р	I/O bit or word
	М	Auxiliary bit or word
	K	Keep(non-volatile) relay (bit or word)
Area	L	Link relay (bit or word)
Key	Т	Timer
	С	Counter
	F	Special relay (bit or word)
	S	Step controller
	D	Data register
Number	0~9	Inputs numbers such as Adderss I/O relay No. Data Pagister No.
Key	A ~ F	inputs numbers such as Adderss, 1/0 felay No., Data Register No.
	PRM	Get into the parameter editting status.
	EPRM	Used when read or write a user program to EPROM.
	ON (8)	Forces a relay ON
	OFF (9)	Forces a relay OFF
	CD (A)	Set the operands(P, L, M, K, F, S) unit as word
Other	H (B)	Inputs hexadecimal numbers
Key	• (-) (C)	Minus(-) (e.g. Timer reference value)
		Dealing step controller (S area)
	# (D)	Indirect addressing of a Data Register
	F+ (E)	Increases the function number of application functions
	F- (F)	Decreases the function number of application functions
	AUX	Select an auxiliary function
	MON	Monitor a device

- 14 -

3.4 Word, bit description of memory

1) K10S1 ~ K500H



2) MK1000H, GK3, 4, 5



- 15 -

3.5 Mode Description

KLD-150S is a programming tool for MASTER - K Seriese PLC. There is four operating modes.

Program	Mode	(PGM)
Run	Mode	(RUN)
Debug	Mode	(DEB PAU)
Pause	Mode	(DEB PAU)

1) Mode selection

Each mode can be selected as shown below.

Mode LED turns on with respect to the current mode.

Mode	Mode Key	LED
PGM (Program Mode)	RUN PGM	PGM LED
RUN (Run Mode)		RUN LED
DEB (Debug Mode)	PAUSE DEBUG	PGM + PAU
PAU (Pause Mode)	Error message displays when error occurs changing the mode from PGM to RUN	RUN + PAU

- 16 -

2) Mode selection

	Mode	Functions	
		Program read	
		Monitoring reference and current value of devices	
	RUN /	Device forced On/Off, changing the current value	
	PAUSE	of card, timer/Counter	
		Command and operand search	
		Step monitor	
		Scan time measure	
	PGM	EPROM Write	
	PAUSE	EPROM Read/Write/Check/Verify	
	PGM	Power On	
	RUN	Mode change	
	PAUSE	Password register and change	
KLD-150S Handy		Program input, insert, delete	
Loader	PGM	Bit, card, step monitor	
		Bit, Card and Timer/Counter current value change	
		Command and operand search	
		Program delete	
		Operand replace	
		Set/Delete the parameters	
		I/O table set and monitor	
		Latch area set	
		HSC (High Speed Counter) set	
	DEBUG	Trace run (Execut each step)	
		Step break run (Stop at specific step)	
		Scan break run (Executes specific times of scan then stop)	
		Value break run (Stops when the specific bit or card	
		value reachs to the reference value)	

- 17 -

CHAPTER 4 KEY OPERATION



- 18 -

4.2 MODE CHANGE



- 19 -



 For K30S, K60S type, select 1st item, for K10S, K10S1, 60H, 200H type select 3rd item and for K250, 500H, 1000H, K200S, K300S, K1000S type select 5th item in PLC parameter menu. Methods of Registering, deleting, changing password are same with K200S.

- 20 -



- 21 -



- 22 -



- 23 -



4.7 PROGRAM EXAMPLE

Note 1) In the Debug mode, execution select menu is displayed wh^{SHFT} CLR ' key is pressed.
D E B U G # # I I I M O D E I </td
D E B U G # # # se O D E D E O CLR
1 . T R A C E 2 . S T E P 3 . S C A N 4 . V A L U E
Note 2) If you try to input the number that is greater than the maximum step value, it won't be fed.
Remarks
1) If you read a step and press ' $\begin{bmatrix} STEP \\ \blacktriangle \end{bmatrix}$, $\begin{bmatrix} STEP \\ \blacktriangledown \end{bmatrix}$ ' key without modifying the command,
 KLD-150S reads the previous/next step. If you press ' STEP . STEP . STEP ' key after modifying the command, KLD-150S reads current step.
3) Decreasing/Increasing of step number caused by pressing \mathbf{x}^{STEP} \mathbf{x}^{STEP} 'key is as follows.
General command(excluding S area), application command : occupies 1 step
General command(involved with S area), single area application command : occupies 2 steps
Application command whose operands are double lenth devices (Decimal, Hexadecimal) : occupies 4 step
Ex) DMOV M00 P00 DMOV 510 D000
$1 \text{ step} + 2 \text{ step} + 2 \text{ step} = 5 \text{ step} \qquad 1 \text{ step} + 4 \text{ step} + 2 \text{ step} = 7 \text{ step}$

- 25 -



- 26 -



- 27 -



0	0	0	0	2	d							
Т	0	N						Т	0	0	0	

- 28 -

00006

< 2

мIDD

ΕR

P000



- 29 -



- 30 -



- 31 -





- 33 -



Note1) Up to 2 words can be monitored simultaneously, and 4 words can be input.

That is to say, 2 words are memorize and once key is pressed, words shift right so that you can certify the contents again. Press key, whole words rotate left and you can monitor its contents.

Note2) Other PLCs except the New Master - K series can monitor up to 3 word.

- 34 -



- 35 -



1) Even though a bit is set by forcing On/Off, the value of the bit can be changed if it is used by user program.

2) 'F' device can not be forced On/Off.

- 36 -



- 37 -




4.18 DESCRIPTIONS



- 40 -



1) 'D word No.' is displayed as a reference when D area device is used for timer/counter reference.

- 41 -



1) A reference value cannot be changed if it is set as D area device in program mode. Also a reference value that is in decimal/hexa(number) form cannot be changed into D area device.

- 42 -



- 43 -



1) Timer/counter forced on/off function is not available with K200S, K300S, K1000S.

- 44 -



- 45 -



- 46 -



- 47 -



- 48 -



- 49 -

4.26 ERROR MODE SETTING



There is no fuse error item for K200S.

- 50 -







- 52 -



- 53 -



- 54 -

Loader display	Key operations	Description
0 0 0 1	STEP	
0 0 0 1	(STEP) ▼	
0 0 0 0 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	STEP V	
0 0 0 4	STEP V	
0 0 0 5	STEP ▼	In case of application command, middle step does not shown on the screen. Step number of following command appears on next trace.
0 0 1 0		
1 . T R A C E 2 . S T E P 3 . S C A N 4 . V A L U E		Shows the function menu of debugging.

- 55 -





4.33 VALUE BREAK RUN



- 58 -



- 59 -

4.34 PROGRAM PARTIAL CLEAR



- 60 -

4.35 DEVICE DATA CLEAR



- 61 -

4.36 DATA BLOCK CHANGE



- 62 -

4.37 BLOCK MOVE/COPY



4.38 BLOCK MOVE/COPY DESCRIPTION



- 64 -



All the steps from step0 to the last step are filled with the 'NOP'.

- 65 -

4.40 EPROM BLANK CHECK



- 66 -

4.41 EPROM WRITE

Available mode		Note
RUN/PAU PGM DEB × × × Transfer the PLC user program to the F mounted on the KEW-150S.	PLC Write ROM Pack CPU rogram area) ROM Pack or RAM Pack on KEW-150S	
Loader display	Key operations	Description
0 0 0 0 .	PGM CLR EPRM	Select EPROM or flash memory. (This message is shown only for K200S)
1 . E . C H K . 2 . W R I T E 3 . V E R I F Y 4 . R E A D	2	EPROM function menu.
* C H E C K E P R O M * 1 2 8 K R O M <	STEP ▼ × 2	Select appropriate ROM.
* C H C K E P R O M * 2 5 6 K R A M <	ENT	
* E P R O M W R I T E * * * 0 3 6 8 S T E P * *		Transfer the PLC user program to the EPROM, RAM Pack.
* E P R O M W R I T E * * * C O M P L E T E D I * *	CLR	Execution complete.
1 . E . C H K 2 . W R I T E 3 . V E R I F Y 4 . R E A D		EPROM function menu.

1) When there is an error during writing an EPROM, following message appears.

	*	E	Ρ	R	0	М		W	R	I	Т	E	*	
*	*		F	A	I	L	Ε	D		İ			*	*

- 67 -

4.42 EPROM VERIFY

Available mode		Note					
RUN/PAU PGM DEB	DLC Vetify DOM Deals						
	CPU CPU ROM Pack						
Compare and verify the contents of EP	(program area) on KEW-150S						
the PLC user program.	(program area)						
Loader display	Key operations	Description					
0000							
1.EPROM WRITER		Select EPROM or flash memory					
		(This message is shown only for K200S)					
		EDDOM function many					
		EPROM function menu.					
3. VERIFY4. READ	2						
* CHECK EPROM*	(0750)	Select appropriate ROM.					
1 2 8 K R O M < E N T >	×3						
* CHECK EPROM*	_						
256K ROM < ENT >	ENT						
* E P R O M V E R I F Y *		Compare and verify the contents of EPROM,					
** 0567 STEP **		RAM pack with PLC user program.					
* E P R O M V E R I F Y *		Execution complete					
	CLR	Execution complete.					
		EPROM function menu.					
3 . V E R I F Y 4 . R E A D							

1) When there is an error during verifying an EPROM, following message appears.

* E P R O M V E R I F Y * FAILED * * * * 1

- 68 -

4.43 EPROM READ Available mode Note RUN/PAU PGM DEB Read × PLC ROM Pack 4 CPU or RAM Pack Transfer the contents of EPROM, RAM(pack) mounted on on KEW-150S (program area) the KEW-150S to the PLC user program area. Key operations Loader display Description 00000 LOAD 000 мо Select EPROM or flash memory. (This message is shown only for K200S) 1 EPROM function menu. 2 Select appropriate ROM. STEP ▼ × 3 ENT ROM ΕN 2 EPROM READ Reading EPROM, RAM pack, transfer it to PLC program area. ۱۸ RF Execution complete. CLR EPROM function menu.

1) When there is an error during reading an EPROM, following message appears.

 *
 E
 P
 R
 O
 M
 R
 E
 A
 D
 *

 *
 *
 F
 A
 I
 L
 E
 D
 !
 *
 *

- 69 -

4.44 SCAN TIME DISPLAY Available mode Note RUN/PAU PGM DEB × × Display the minimum value, current value, Shows the 1 scan elapsed time for K200S,K300S,K1000S. For maximum value of 1 scan elapsed time. K10S,K30S,K60S current reference of high speed counter desplayed. Loader display Key operations Description 00000 Step monitoring status in RUN mode. CLRCLR LOAD м 0 0 0 0 00000 MON Shows the 1 scan elapsed time. CLR 00 00000 STEP 00000 Step monitoring status in RUN mode. LOAD 00 0 Note

1) The unit of scan time is 'msec'

2) The unit become 'sec' when the scan time exceeds 100 msec.

ex) 64.6 64.6 msec

2.04 s 2.04 sec

- 70 -



- 71 -





- 72 -



- 73 -


- 74 -



- 75 -



- 76 -



- 77 -



- 78 -



- 79 -



Note

You can set the 'HS link parameter' only when 'HS link enable' is set at 'No'.

- 80 -



- 81 -

Loader display	Key operations	Description
L I N K C O N T R O L A C C E S P R O T I N O	(m 8)	
L I N K C O N T R O L A C C E S P R O T : Y E S	ENT	Enable the protection that prohibits reading/writing PLC data for host PC.
L I N K C O N T R O L L I N K E N A B L E I N O L I N O I I I N O I I I I N O I	ON 8	
L I N K C O N T R O L L I N K E N A B L E : Y E S	ENT	Execute HS data link.
L I N K C O N T R O L S E L F _ S T . N O . : h O 0	1 ENT	Define self station number.

- 82 -



- 83 -



- 84 -

4.57 TIMER SETTING



- 85 -



- 86 -



- 87 -



- 88 -



- 89 -



- 90 -



- 91 -



- 92 -

4.64 PLC INFORMATION VIEW Available mode Note RUN/PAU PGM DEB × × For GK3/GK4/GK5 / K300S/K1000S Shows the PLC kind and the flash memory kind. (Except K200S) Loader display Key operations Description . I N F O R M A T I O N . E X E C U T I O N 1 1. PLC information 1 ENT 2. EPROM check, write, verify, read. 2 мКS PLC kind and flash memory kind. CLRCLR You can exit by pressing CLR key twice. 64KBy F мЕм

- 93 -



- 94 -



- 95 -



- 96 -

4.68 MASTER	- K	FUNCTION	COMPA	RISON	TABLE
-------------	-----	-----------------	-------	-------	-------

			PRODUCT				
No.		FUNCTIONS	K10S/K30S/ K60S/K100S	K200S	K300S	K1000S	
1	Init.	EPROM Write/Program					
1	Init. screen	Product and Version Display					
		On connecting					
2	Back- light	Turn off after 10 minute since last key operation.					
3	Mo	de Change					
4	Pas	sword Registration					
5	Pas	sword Change and Clear					
6	Pro	gram Input and Modification					
7	Pro	gram Read					
8	Pro	gram Insert					
9	Pro	gram Delete					
10	Pro	gram Check			/	/	
11	Dev	vice Search(Bit)					
12	Inst	truction Search					
13	Ste	p Monitor					
14	Bit	Monitor					
15	Wo	rd Monitor					
16	Bit	Current Value Change					
17	Wo	rd Forced On/Off					
18	Wo	rd Current Value Change					
19	Tin	ner/Counter Input					
20	Tin	ner/Counter Monitor					
21	Tin	ner/Counter Reference Change					

- 97 -

		1	PRODUCT					
No.	FUNCTIONS	K10S/K30S/ K60S/K100S	K200S	K300S	K1000S			
22	Timer/Counter Forced On/Off			/	/			
23	Change Timer/Counter Current Value							
24	HSC Data Setting			/	/			
25	HSC Default PRM Write			/	/			
26	Latch Area Setting	/						
27	W.D.T Setting	/	/					
28	Error Mode Setting	/	/					
29	I/O Table Setting	/	/					
30	Link Parameter	/	/					
31	Link Control	/						
32	Timer Set	/	/					
33	Interrupt	/	/					
34	Baud Rate		/					
35	I/O Table Monitor	/						
36	Default Parameter Write							
37	1 Step Run	/						
38	Step Break Run	/						
39	Scan Run	/						
40	Value Break Run	/						
41	Program Partial Clear							
42	Program Data Clear							
43	Block Data Change							
44	Block Move, Copy							
45	Program All Clear							

- 98 -

CHAPTER 5 TROUBLESHOOTING

5.1 MASTER-K10/K60H/K200H (Indiccated on the F05 Word)

Error	Error Code	CPU Status	Cause	Corrective Action	K10	K60H	K200H	K250
OS ROM CHK.SUM. Error	10	Stop	Defection of operating ROM or check sum mismatch	Please contact service station.				
Memory Error	11	Stop	Fault of the internal system RAM	Please contact service station.				
Gate Array Error	12	Stop	Fault on the sequence instruction processing LSI	Please contact service station.				
24V Down Error	13	Stop	Abnormal 24V output of main, expansion and power unit	Exchange with spare unit or contact service station				
I/O Slot		<i>a</i> .	Mounting or unmounting I/O units during run. Or Bad contact.	Turn off the power and insert right and run again				
Error	ror 14 Stop		14 Stop I/O unit fault or expansion unit Change I/O unit or expansion cable fault cable					
WDT Over	20	Stop	Scan time exceeds the WDT time	Measure maximum scan time first. And then modify parameter or insert WDT command in program				
Parameter CHK.SUM Error	21	Stop	Parametr is modified or check sum mismatching	Modify parameter				
Code Error	23	Stop	CPU is unable to compile the commands	Modify the wrong step or if it is under ROM dirve mode, replace the ROM				
Missing End Error	24	Stop	There is no 'END' in program.	Add 'END' command at the end of the program (Be aware of JMP- JME block)				
Missing RET Error	25	Stop	There is no 'RET' command at the end of the subroutine	Add 'RET' command at the end of the program (Be aware of JMP- JME block)				
Operation Error	26	Continue (Stop)	There is a digit that is not 0 ~ 9 Exeeds the specified operand area	Modify the wrong step				
I/O Check Error	27	Continue	I/O unit information mismatches with the real I/O unit kind when the power is on or starting run	Modify parameter or rearrange I/O unit or change I/O unit				
Lower Battery Voltage	28	Continue	Back-up battery voltage is low	replace the battery				
Fuse (K250 Only)	29	Continue (Stop)	input/output mixing, output unit fuse is blown	Certify the fuse LED, turn off the power and then replace the fuse				

- 99 -

5.2 MASTER-K500H/K1000H (Indicated on the F06 word)

Error	Error code	CPU Status	Cause	Corrective Action
Internal system error	H1001	Stop	Defection of operating ROM or H/W error Please contact service station.	
Memory Destroyed	H1002	Stop	Fault of the internal system RAM	Please contact service station.
Gate Array Destroyed	H1003	Stop	Fault on the sequence instruction processing LSI	Please contact service station.
Sub Rack Power Down Error	H1004	Stop	Expansion rack power down	Examine the power of expansion rack
I/O Slot Verify Error	H2001	Stop	Mounting or unmounting I/O units during run. Or Bad contact. I/O unit fault or expansion unit cable fault	Turn off the power and insert right and run again Change I/O unit or expansion cable
Fuse Break Error	H2002	Conti- nue (Stop)	input/output mixing, output unit fuse is blown	Certify the fuse LED, turn off the power and then replace the fuse
Special Card Interface Error	H2003	Stop	Error occurrs during special card interfacing	Please contact service station.
WDT Over	H2004	Stop	Scan time exceeds the WDT time	Measure maximum scan time first. And then modify parameter or insert WDT command in program
Operation Error	H2005	Conti- nue (Stop)	There is a digit that is not 0 ~ 9 Exeeds the specified operand area	Modify the parameter
Parameter CHK.SUM Error	H3001	Stop	Parametr is modified or check sum mismatching	Modify the parameter
Maximum I/O Over	H3002	Stop	Exceeds maximum 512 point by reserved I/O or mounted I/O unit	Modify the parameter or exchange the I/O unit with the less point one
Instruction Code Error	H3003	Stop	CPU is unable to compile the commands	Modify the wrong step or if it is under ROM dirve mode, replace the ROM
Missing End Program	H3004	Stop	There is no 'END' in program.	Add 'END' command at the end of the program (Be aware of JMP-JME block)
Missing RET Program	H3005	Stop	There is no 'RET' command at the end of the subroutine	Add 'RET' command at the end of the program (Be aware of JMP-JME block)
I/O Verify Error	H3006	Conti- nue (Stop)	I/O unit reserved information is different form the real mounted I/O unit when the power is on or starting run	replace the battery
Battery Error	H3007	Conti- nue	Back-up battery voltage is low	Please contact service station.

() can be modified in parameter

- 100 -

Error	Error code	CPU status	Cause	Corrective Action
DLU Interface Error	H4001	Conti- nue	H/W error occurs during DLU card interfacing	Please contact service station.
DLU Parameter Setting Error	H4002	Conti- nue	There is an error with yor DLU parameter	Check DLU parameter area and set again.
DLU Failure	H4003	Conti- nue	Error occurrs during link executing	Check DLU card.
DLU Unit Self –Check Error	H4004	Conti- nue	DLU self error check.	Check DLU card.
DLU Unit Parameter Error	H4005	Conti- nue	DLU unit parameter error during run	Check DLU card.
RMU1 Interface Error	H4011	Conti- nue	H/W error occurrs interfacing with RMU1 card	Please contact service station.
RMU1 Parameter Setting Error	H4012	Conti- nue	Wrong RMU1 parameter	Check RMU1 parameter area and set again.
RMU1 Failure	H4013	Conti- nue	Error occurrs during RMU1 link executing	Check RMU1 card.
RMU1 Unit Self-Check Error	H4014	Conti- nue	Self-check error during run	Check RMU1 card.
RMU1 Unit Parameter Error	H4015	Conti- nue	RMU1 unit parameter error during run	Check RMU1 card.
RMU2 Unit Interface Error	H4021	Conti- nue	H/W error occurrs interfacing with RMU2 card	Please contact service station.
RMU2 Parameter Setting Error	H4022	Conti- nue	Wrong RMU2 parameter	Check RMU2 parameter area and set again.
RMU2 Failure	H4023	Conti- nue	Error occurrs during RMU2 link executing	Check RMU2 card.
RMU2 Unit Self-Check Error	H4024	Conti- nue	RMU2 unit Self-check error	Check RMU2 card.
RMU2 Unit Parameter Error	H4025	Conti- nue	RMU2 unit parameter error during run	Check RMU2 card.
RMU3 Unit Interface Error	H4031	Conti- nue	H/W error occurrs interfacing with RMU3 card	Please contact service station.

- 101 -

Error	Error code	CPU Status	Cause	Corrective Action
RMU3 Parameter Setting Error	H4032	Conti- nue	Wrong RMU3 parameter	Check RMU3 parameter area and set again.
RMU3 Failure	H4033	Conti- nue	Error occurrs during RMU3 link executing	Check RMU3 card.
RMU3 Unit Self-Check Error	H4034	Conti- nue	RMU3 unit Self-check error	Check RMU3 card.
RMU3 Unit Parameter Error	H4035	Conti- nue	RMU3 unit parameter error during run	Check RMU3 card.

5.3 MASTER-K10S/K30S/K60S/K100S

Error	CPU Status	Cause	Corrective Action
I/O Error	Stop	Expansion unit mounting error	Certify the expansion unit and power Off On
Code Error	Stop	User program error	Modify the error step
Parameter Error	Stop	PLC program error	Modify the parameter
Missing End	Stop	There is no 'END' in user program	Insert 'End'
Missing RET	Stop	There is no 'RET' in user program	Insert 'RET'

- 102 -

Error	Message	Error code	CPU Status	Cause	Corrective Action
OS ROM CHK.SUM. Error	OS ROM CHK.SUM. Error	10	Stop	Defection of operating ROM or check sum mismatch	Please contact service station.
Memory Error	Memory Error	11	Stop	Fault of the internal system RAM	Please contact service station.
Gate Array Error	Gate Array Error	12	Stop	Fault on the sequence instruction processing LSI	Please contact service station.
24V Down Error	24V Down Error	13	Stop	Abnormal 24V output of main, expansion and power unit	Exchange with spare unit or contact service station
I/O Slot Error	I/O Slot Error	14	Stop	Mounting or unmounting I/O units during run. Or Bad contact.	Turn off the power and insert right and run again
				I/O unit fault or expansion unit cable fault	Change I/O unit or expansion cable
WDT Over	WDT Over	20	Stop	Scan time exceeds the WDT time	Measure maximum scan time first. And then modify parameter or insert WDT command in program
Parameter CHK.SUM Error	Parameter CHK.SUM Error	21	Stop	Parametr is modified or check sum mismatching	Modify the parameter
Code Error	Code Error	23	Stop	CPU is unable to compile the commands	Modify the wrong step or if it is under ROM dirve mode, replace the ROM
Missing End Error	Missing End Error	24	Stop	There is no 'END' in program.	Add 'END' command at the end of the program (Be aware of JMP-JME block)
Missing RET Error	Missing RET Error	25	Stop	There is no 'RET' command at the end of the subroutine	Add 'RET' command at the end of the program (Be aware of JMP-JME block)
Operation Error	Operation Error	26	Conti- nue (Stop)	There is a digit that is not 0 ~ 9 Exeeds the specified operand area	Modify the error step
I/O Check Error	I/O Check Error	27	Conti- nue	I/O unit information mismatches with the real I/O unit kind when the power is on or starting run	Modify parameter or rearrange I/O unit or change I/O unit
Lower Battery Voltage	Lower Battery Voltage	28	Conti- nue	Back-up battery voltage is low	replace the battery
Fuse(K250 Only)	Fuse(K250 Only)	29	Conti- nue (Stop)	input/output mixing, output unit fuse is blown	Certify the fuse LED, turn off the power and then replace the fuse

5.4 GLOFA-K3, K4 and K5 (Indicated on the F06 Word)

- 103 -

Error	Message	Error code	CPU Status	Cause	Corrective Action
Internal system error	System Error	0001h	Stop	Defection of operating ROM or H/W error	Please contact service station.
OS ROM Error	OS ROM Error	0002h	Stop	Defection on internal system ROM	Please contact service station.
OS RAM Error	OS RAM Error	0003h	Stop	Defection on internal system RAM	Please contact service station.
Data RAM Error	Data RAM Error	0004h	Stop	Defection on data RAM	Please contact service station.
Program RAM Error	PGM RAM Error	0005h	Stop	Defection on program RAM	Please contact service station.
Gate Array Error	G/A Error	0006h	Stop	Fault on the sequence instruction processing LSI	Please contact service station.
SUB Rack Power Down Error	SUB Power Error	0007h	Stop	Expansion rack power down	Examine the power of expansion rack
OS WDT Error	OS WDT Error	0008h	Stop	Watch Dog Timer Error	Power Off and On Contact service center
RAM Error	Common RAM Error	0009h	Stop	Public RAM I/F Error	Please contact service station.
Fuse Break Error	I/O Fuse Error	000Ah	Conti- nue (Stop)	Input/output mixing or output unit fuse is blown	Certify the fuse LED, turn off the power and then replace the fuse
Instruction Code Error	OP Code Error	000Bh	Stop	CPU is unable to compile the commands	Please contact service station.
Flash Mem. Error()	User Mem Error	000Ch	Stop	Flash Memory access error	Certify the flash memory and replace
I/O Slot Error	I/O Slot Error	0010h	Stop	Mounting or unmounting I/O units during run. Or Bad contact. I/O unit fault or expansion unit cable fault	Turn off the power and insert right and run again Change I/O unit or expansion cable
Maximum I/O Over	MAX I/O Over	0011h	Stop	Mounted I/O unit exceeds the maximum I/O point	Replace the I/O unit

5.5 K200S, K300S, K1000S (Indicated on the F06 Word)

- 104 -

Error	Message	Error code	CPU Status	Cause	Corrective Action		
Special Card Interface Error	Special I/F Error	0012h	Stop	Error occurrs during special card interfacing	Please contact service station.		
FMM 0 I/F Error	FMM 0 I/F Error	0013h	Stop	FMM 0 I/F Error	Please contact service station.		
FMM 1 I/F Error	FMM 1 I/F Error	0014h	Stop	FMM 1 I/F Error	Please contact service station.		
FMM 2 I/F Error	FMM 2 I/F Error	0015h	Stop	FMM 2 I/F Error	Please contact service station.		
FMM 3 I/F Error	FMM 3 I/F Error	0016h	Stop	FMM 3 I/F Error	Please contact service station.		
Parameter Error	Parameter Error	0020h	Stop	Parametr is modified or check sum mismatching	Modify the parameter		
I/O Parameter Error	I/O PARA Error	0021h	Conti- nue (Stop)	I/O unit information mismatches with the real I/O unit kind when the power is on or starting run	Modify parameter or rearrange I/O unit or change I/O unit		
Maximum I/O Over	I/O PARA Over	0022h	Stop	Mounted I/O unit exceeds the maximum I/O point	Modify the parameter		
FMM 0 Parameter Error	FMM 0 PARA Error	0023h	Stop	FMM 1 Parameter Error	Modify the parameter		
FMM 1 Parameter Error	FMM 1 PARA Error	0024h	Stop	FMM 2 Parameter Error	lodify the parameter		
FMM 2 Parameter Error	FMM 2 PARA Error	0025h	Stop	FMM 3 Parameter Error	Modify the parameter		
FMM 3 Parameter Error	FMM 3 PARA Error	0026h	Stop	FMM 4 Parameter Error	Modify the parameter		
Operation Error	Operation Error	0030h	Conti- nue (Stop)	There is a digit that is not 0 ~ 9 Exeeds the specified operand area	Modify the wrong step		
WDT Over	WDT Over Error	0031h	Stop	Scan time exceeds the WDT time	Measure maximum scan time first. And then modify parameter or insert WDT command in program		
Run Program Check Error	PGM Change Error	0032h	Conti- nue	Error occurrs when modifying the user program during run (No SBRT, JME, END.) SBRTx.).			
Program Check Error	PGM Check Error	0033h	Conti- nue	Error has occurred during program check	Please contact service station.		

- 105 -

Error	Message	Code	CPU Status	Cause	Corrective Action		
Code Check Error	Code Check Error	0040h	Stop	CPU is unable to compile the commands	Modify the wrong step		
Missing End Program	Miss End Error	0041h	Stop	There is no 'END' in program.	Add 'END' command at the end of the program (Be aware of JMP-JME block)		
Missing RET Program	Miss RET Error	0042h	Stop	There is no 'RET' command at the end of the subroutine	Add 'RET' command at the end of the program (Be aware of JMP-JME block)		
Missing SBRT Program	Miss SBRT Error	0043h	Stop	There is no SBRT command	Insert 'SBRT' at the end of the program (Be aware of JMP~JME block)		
JMP ~ JME command error	JMP(E) Error	0044h	Stop	JMP ~ JME command error	Modify JMP ~ JME command in program		
NEXT command error	FOR ~ NEXT Error	0045h	Stop	FOR ~ NEXT command error	Modify FOR ~ NEXT command in program		
MCS ~ MCSCLR instruction Error	MCS ~ MCSCLR Error	0046h	Stop	MCS ~ MCSCLR command error	Modify MCS ~ MCSCLR command in program		
MPUSH ~ MPOP command err.	MPUSH ~ MPOP Error	0047h	Stop	MPUSH ~ MPOP command error	Modify MPUSH ~ MPOP command in program		
Dual Coil Error	Dual Coil Error	0048h	Stop	Timer, counter is duplicated in program	Modify timer, counter		
Syntax Error	Syntax Error	0049h	Stop	Wrong input condition or too many 'Load, And, (or)Load'	Program check and modify		
Battery Error	Battery Error	0050h	Conti- nue	Back-up battery voltage is low Replace the battery			

- 106 -

CHAPTER 6 DIMENSIONS

<KLD - 150S>



- 107 -

CHAPTER 7 KEW-150S DESCRIPTION & DIMENSIONS

1. Features

KEW - 150S EPROM Writer is a unit of MASTER-K Series and performs saving operations and off-line functions.

1) Performs EPROM read, write, blank check, verify operations.

- 2) Off-line functions (K10 ~ K200)
- 3) 'Write' LED turns on during EPROM writing.

2. Appearances and Names of Main Parts



3. Handling Precautions

Be sure to turn off the Handy Loader(KLD-150S) power before connecting KEW-150S.

4. Directions for Use

Refer to the EPROM usage part of KLD-150S User's Manual.

- 108 -

Function No.	0	1	2	3	4	5	6	7	8	9
00x	NOP	END	STC	CLC	RET	MPUSH	MLOAD	MPOP	STOP	CLE
01x	MCS	MCSCLR	JMP	JME	CALL	CALLP	SBRT	D	DNOT	
02x	INC	INCP	DINC	DINCP	DEC	DECP	DDEC	DDECP	LD=	LDD=
03x	ROL	ROLP	DROL	DROLP	ROR	RORP	DROR	DRORP	LD>	LDD>
04x	RCL	RCLP	DRCL	DRCLP	RCR	RCRP	DRCR	DRCRP	LD<	LDD<
05x	CMP	CMPP	DCMP	DCMPP	TCMP	TCMPP	DTCMP	DTCMPP	LD>=	LDD>=
06x	BCD	BCDP	DBCD	DBCDP	BIN	BINP	DBIN	DBINP	LD<=	LDD<=
07x	WSFT	WSFTP	MULS	MULSP	BSFT	BSFTP	DMULS	DMULSP	LD⇔	LDD
08x	MOV	MOVP	DMOV	DMOVP	CMOV	CMOVP	DCMOV	DCMOVP	DIVS	DIVSP
09x	GMOV	GMOVP	FOMV	FOMVP	AND=	ANDD=	AND>	ANDD>	AND<	ANDD<
10X	BMOV	BMOVP	XCHG	XCHGP	DXCHG	DXCHGP	AND>=	ANDD>=	AND<=	ANDD<=
11X	ADD	ADDP	DADD	DADDP	SUB	SUBP	DSUB	DSUBP	AND	ANDD <>
12X	MUL	MULP	DMUL	DMULP	DIV	DIVP	DDIV	DDIVP	DDIVS	DDIVSP
13X	ADDB	ADDBP	DADDB	DADDBP	SUBB	SUBBP	DSUBB	DSUBBP	PIDTUN	PIDCAL
14X	MULB	MULBP	DMULB	DMULBP	DIVB	DIVBP	DDIVB	DDIVBP		
15X	WAND	WANDP	DWAND	DWANDP	WOR	WORP	DWOR	DWORP	RECV	SEND
16X	WXOR	WXORP	DWXOR	DWXORP	WXNR	WXNRP	DWXNR	DWXNRP	RCV	SND
17X	BSUM	BSUMP	DBSUM	DBSUMP	SEG	SEGP	ENCO	ENCOP	DECO	DECOP
18X	FILR	FILRP	DFILR	DFILRP	FILW	FILWP	DFILW	DFILWP	OR=	ORD=
19X	ASC	ASCP	UNI	UNIP	DIS	DISP	OR>	ORD>	OR<	ORD<
20X	IORF	IORFP	WDT	WDTP	FALS	DUTY	FOR	NEXT	OUTOFF	
21X	HSCNT	DIN	DINP	DOUT	DOUTP	HSC	OR>=	ORD>=	OR<=	ORD<=
22X	BREAK	EI	DI	BSET	BRST	IRET	TDINT	INT	OR⇔	ORD 🗢
23X	GET	GETP	RGET	RPUT	PUT	PUTP	BOUT	SR	EI	DI
24X	NEG	NEGP	DNEG	DNEGP	READ	WRITE	CONN	STATUS	BLD	BLDN
25X	BAND	BANDN	BOR	BORN						

[Appendix] Handy Loader Instruction Code Table

Caution

: Valid only for K1000S, K300S, K200S Series

: Valid only for K10S,K10S1, K30S, K60S Series

: Valid only for K200S B/C Type

: Valid only for K10S,K10S1, K30S, K60S, K200S C Type

- 109 -